

Assembly Instructions

Parts Identification:

PRINTHOLDER

- (1) Frame
- (2) 7/8" Square connecting tube
- (3) Shelf
- (4) Casters
- (5) #10x $\frac{1}{2}$ " long sheet metal screws
- (6) $\frac{1}{4}$ x20x2" long allen key screws

Parts in plastic bag include:

Four casters (two with brakes and two without brakes), sixteen $\frac{1}{4}$ x20x2" screws, eight #10x $\frac{1}{2}$ " long sheet metal screws and one allen key

1. Tap in casters into plastic inserts at bottom of frame. Use one with brakes and one without brakes per frame.
2. Connect both frames with eight 7/8" tubing, (item 2), by means of sixteen $\frac{1}{4}$ x20x2" long screws, (item 6).

Note: Make certain that casters of same type are facing you at this point.

3. Place trays, (item 3), between frame ends and secure with eight #10x $\frac{1}{2}$ " long sheet metal screws (item 5).

4. Unit is now ready for use.

